





## Linear feeders drives



Model

Size

	A	B	C	D	E	F	HØ	I	L	M	N	O
AL-15	50	130	58	30	105	14	15	15	M4	39	58	17,5
AL-30	80	235	101	50	150	13	25	20	M6	50	141	15
AL-35	75	220	105	50	190	15	25	20	M6	60	105	5
AL-40	90	291	111	55	185	21,5	25	20	M6	65	180	21,5
AL-75	100	330	150	65	288	21	30	20	M8	70	175	35
AL-80	124	475	174	76	380	32	40	30	M8	80	290	20
AL-90	204	633	220	148	490	33	51	30	M10	170	425	20



234 661 888



917 390 183



234 661 889



comercial@permarind.com



Apartado 453 • 3754-909 • Águeda • Vale do Grou • E.N.1 • Portugal




www.permarind.com



# PERMARIND

# brovind®



**Model**

**Size**

	A	B	C	D	E	F	HØ	I	L	M	N	O	P
<b>AL-25</b>	75	230	118	50	160	20	25	20	M6		60	44	7Ø
<b>AL-50</b>	135	245	159	79	144	31	25	20	M6	44	96	13	9Ø
<b>AL-55</b>	150	275	171	100	175	28	30	20	M8	80	135	6	9Ø
<b>AL-65</b>	190	313	184	150	200	27	<b>30</b>	20	M8	80	135	4.5	9Ø



234 661 888



917 390 183



234 661 889



comercial@permarind.com



Apartado 453 • 3754-909 • Águeda • Vale do Grou • E.N.1 • Portugal



www.permarind.com

